



Peppe

GRIND SETTING GUIDE



how to adjust
the grind setting





Why did we create this guide?

Every brewing method has a recommended grind size range. With this guide, we want to help you find the most suitable range for your needs.

How did we arrive at the recommended range and the sweet spot?

In our laboratories, we have identified not only the **recommended range** for each brewing method, but also the **sweet spot** which, according to our tests performed with different coffees, is the most grind size to fully enhance and extract the flavours of your recipe.

As every coffee has different properties, your sweet spot may be a little different from ours. Start with our recommendation and find the sweet spot that suits you best!

ESPRESSO

Recommended range:

From Value 1 in the Round 1 to Value 5 in the Round 1


Sweet spot

recommended by Eureka:

Value 1 in the Round 1 for light/medium roasted

Value 2 in the Round 1 for medium/dark roasted

Note: Your PEPPE comes pre-set for **Espresso** grinding and is ready to use immediately after opening the box.




MOKA

Recommended range:

From Value 4 in the Round 1 to Value 9 in the Round 1

Sweet spot recommended by Eureka:

Value 5,5 in the Round 1 for both light/medium roasted and medium/dark roasted



V60


Recommended range:

From Value 0 in the Round 2 to Value 0 in the Round 3
(the whole 2nd round)

Sweet spot

recommended by Eureka:


Value 5 in the Round 2 for both light/medium roasted and medium/dark roasted



CHEMEX

Recommended range:

From Value 2 in the Round 2 to Value 2 in the Round 3



AEROPRESS

Recommended range:


From Value 5 in the Round 2 to Value 2 in the Round 3

Sweet spot

recommended by Eureka:

Value 5 in the Round 2 for washed coffees

Value 2 in the Round 3 for anaerobic coffees



FRENCH PRESS

Ideal range:


From Value 8 in the Round 2 to Value 5 in the Round 3

Sweet spot


recommended by Eureka:

Value 8 in the Round 2 for washed coffees

Value 5 in the Round 3 for anaerobic coffees



GRIND SIZE RECAP



	SWEET SPOT
Espresso	value 1 in the round 1 for light/medium roasted; value 2 in the round 1 for medium/dark roasted
Moka	value 5,5 in the round 1 for both light/medium roasted and medium/dark roasted
V60	value 5 in the round 2 for both light/medium roasted and medium/dark roasted
Aeropress	value 5 in the round 2 for washed coffees; value 2 in the round 3 for anaerobic coffees
French Press	value 8 in the round 2 for washed coffees; value 5 in the round 3 for anaerobic coffees

Have you changed the grind settings several times but still can't find the ideal setting for a specific brewing?

Reset the grinders to zero point and re-start. Follow these steps.

1



With the grinding chamber empty, **TURN ON THE MOTOR.**

2



TURN THE DIAL CLOCKWISE (to make grind fines) until you hear a slight humming sound, which indicates that the grinders are coming into contact. This is the **ZERO POINT.**

3



TURN THE DIAL ANTI-CLOCKWISE to adjust the grind setting for your favourite brewing method.

4



When you have finished grinding, **TURN OFF THE MOTOR.**